

9.1 Indoor Unit Error Display

42LUVH060K

42LUVH070K

Display	LED STATUS
E0	EEPROM parameter error
E1	Indoor / outdoor units communication protection
E2	Zero-crossing signal error
E3	Fan speed out of control
E5	Open or short circuit of outdoor temperature sensor
E6	Open or short circuit of room or evaporator temperature sensor
E7	Outdoor unit fan protection
P0	Module protection
P1	Over voltage or too low voltage protection
P2	Temperature protection of compressor top.
P4	Inverter compressor drive error

Note: E4 & P3: Reserved function

42LUVH080K

Failure phenomenon	Defrosting lamp	Timer lamp	Auto lamp	Operation Lamp
EEPROM parameter error	On	On	On	On
Indoor / outdoor units communication protection	☆	☆	☆	☆
Zero-crossing signal error	On	On	☆	☆
Fan speed out of control	On	On	☆	☆
Open or short circuit of outdoor temperature sensor	X	On	X	☆
Open or short circuit of room or evaporator temperature sensor	On	On	On	☆
Outdoor unit fan protection	On	On	☆	☆
Module protection	X	X	On	☆
Over voltage or too low voltage protection	X	On	On	☆
Temperature protection of compressor top.	On	X	X	☆
Outdoor temperature low protection	On	X	On	☆
Inverter compressor drive error	On	X	☆	☆

Note: X---Extinguish ☆---Flash at 5Hz