















7-9-1 Indoor fault code (Green LED)

NO (RANK)	ERROR CONTENTS	DISPLAY PATTERN	ALLOWED MODES
1	Power Line Feedback (ZERO CROSSING)		
2	Indoor-outdoor units communication fault		FAN ONLY MODE
3	Room air sensor fault		FAN ONLY MODE
4	Indoor unit coil sensor fault		FAN ONLY MODE
5	Indoor fan motor fault		
6	Indoor sensor wiring reversed		FAN ONLY MODE

7-9-2 Outdoor fault code (Orange LED)

NO (RANK)	ERROR CONTENTS	DISPLAY PATTERN	ALLOWED MODES
1	Outdoor sensor fault 1) Outdoor air 2) Outdoor coil 3) Discharge gas 4) OLP (if used)		FAN ONLY MODE
2	Indoor-outdoor units mis-matching		FAN ONLY MODE
3	4Way Valve Fault		FAN ONLY MODE
4	Outdoor fan motor fault		FAN ONLY MODE
5	Inverter control drive fault		FAN ONLY MODE
6	Power module (IGBT) fault		FAN ONLY MODE
7	Indoor-outdoor units communication fault		FAN ONLY MODE
8	Outdoor high temperature protection		FAN ONLY MODE